

10 x 10 INSTANT CANOPY

Item No. WMT-1010112W
Model No. 30547



For more in-depth videos, setup demonstrations and product information, please visit www.Walmart.com


Before you begin

Read all instructions thoroughly before beginning set up.

- Select a level site clear of rocks, branches, and other hard or sharp objects, to set up your shelter.

⚠ WARNING: Keep clear of overhead power lines.

- Do not set up your shelter under trees because of potential lightning strikes or falling tree limbs in inclement weather.
- Secure with all stakes and guylines provided to prevent property damage or personal injury.
- Two people can easily setup this shelter in minutes.




(1) Frame



(8) Steel Stakes



(1) Stake Bag



(1) Canopy




(1) Carry Bag

SET UP


1 PARTIALLY EXTEND FRAME

Use 2 people, pulling from opposite corners.





3 RAISING ROOF SUPPORT BRACKETS

Press up on support brackets until orange button locks into place.



5 EXTEND LEG POLES TO DESIRED HEIGHT

Grasp and extend telescoping leg poles until the silver locking buttons "click" into locked position.





3-Stage Height Adjustability

- LOWEST
- MEDIUM
- HIGHEST


2 DRAPE CANOPY OVER FRAME

Press the hook and loop pads located at each corner onto frame.





4 SECURE CANOPY TO FRAME

Wrap hook & loop fasteners on underside of canopy around metal brace to secure.



6 STAKE SHELTER & GUYLINES


Drive stake through hole in each leg pole foot. Stake each guyline then tighten and adjust with slider.




(See other side for Take Down Instructions)

TEAR DOWN


1 UNLOCK SUPPORT BRACKETS & COLLAPSE FRAME




2 LOWER LEG POLES



3 REMOVE CANOPY FROM FRAME



4 FOLD & STORE CANOPY & FRAME



Storing the Shelter

- Remove stakes and place in their storage bag.
- All stakes must be placed in their own storage bag before placing in shelter carrying case to prevent damage to the shelter fabric.
- Store in a clean, dry area.

IMPORTANT FACTS:

- Never store shelter, even for a short period of time, without drying it thoroughly and brushing off caked dirt. Do not pack stakes inside your shelter. Use a separate storage bag.
- STAKES SHOULD BE REMOVED BY PULLING ON THE STAKE ITSELF. NEVER PULL ON THE SHELTER TO REMOVE STAKE.
- Do not leave your shelter set-up for weeks at a time. Be aware that exposure to ultraviolet rays from the sun can seriously damage material and/or cause it to become discolored.



WARNING: KEEP ALL FLAME AND HEAT SOURCES AWAY FROM THIS SHELTER FABRIC

This shelter is made of flame-resistant fabric which meets CPAI-84 specifications. **IT IS NOT FIRE-PROOF.** The fabric will burn if left in continuous contact with any flame source. The application of any foreign substance to the product fabric may render the flame-resistant properties ineffective.

DO NOT use fuel burning devices inside or near tent materials.

DO NOT permit children to light matches, operate burning appliances, or handle any flame sources in or near the shelter.

- Do not smoke, use matches, candles or open flames of any kind in or near the shelter.
- Do not refuel lanterns, stoves or heaters inside shelter.
- Do not cook inside shelter.
- Do not store flammable liquids inside shelter.



IMPORTANT:

THE ORIGINAL FIRE RETARDENT AND WATER REPELLENT PROTECTIVE COATINGS MAY BE COMPROMISED IF SPRAYS OR OTHER CHEMICAL TREATMENTS ARE USED ON THE TENT. FABRIC HAS BEEN FACTORY TREATED. IT IS HIGHLY WATER-REPELLANT; HOWEVER, IT IS NOT WATERPROOF. ALL TENTS CAN EXPERIENCE SEAM LEAKAGE DURING WET WEATHER. IF YOU WANT ADDITIONAL MOISTURE PROTECTION, TRY A SEAM SEALING COMPOUND ONLY; STRICTLY FOLLOW THE MANUFACTURER'S DIRECTIONS. IT IS RECOMMENDED THAT YOU SEAL THE TENT DURING THE INITIAL SETUP AS WELL AS PRIOR TO EACH CAMPING SEASON. SEAM SEALER COMPOUNDS CAN BE PURCHASED AT YOUR LOCAL CAMPING PRODUCTS OUTLET. FOR MISSING PARTS CALL 1-888-774-5840. **PLEASE DO NOT RETURN THIS PRODUCT TO THE RETAIL STORE.**

REPAIR PARTS LIST

Part Number	Description
90606	Center Hub
90607	Upper Roof Pole
90608	Roof Joint
90609	Lower Roof Pole
90610	Apex Support Pole
90611	Gazebo Leg
90612	Scissor Bar
90613	Scissor Joint
90614	Scissor Endcap
90615	Canopy

6 Month Limited Warranty

Campvalley (Xiamen) Co., Ltd. warrants for a period of six months from the original date of purchase, this product against any defects in materials or workmanship. At its discretion, Campvalley may provide replacement parts to original purchaser. Original receipt or proof of purchase as well as proof of defect is required. Campvalley will not be responsible for shipping costs incurred outside the continental USA. Warranty is valid for the original purchaser six months from the date of purchase and is not transferable. This Warranty does not cover any product purchased through non-authorized dealers and/or online auction websites.

This Warranty Does Not Cover

This 6 Month Limited Warranty does NOT cover normal wear and tear, abuse or misuse of this product including damage from inclement weather conditions, such as wind, rain, or hail. In case of inclement weather remove all valuables and persons and seek appropriate shelter. **Under no circumstances will Campvalley (Xiamen) Co., Ltd be liable or responsible for any incidental or consequential damages.**

This product is designed and intended for Recreational use only. Prolonged exposure to UV rays will cause any fabric to fade and deteriorate and is NOT covered by this 6 Month Limited Warranty.

All replacement products or parts will assume the remaining warranty of the original product. This warranty gives you specific legal rights. You may also have other rights which vary from state to state.

To Obtain Warranty Service

Call Toll Free 1-888-774-5840 for warranty service, repair parts, or product questions. Mon-Fri, 8:00 a.m. – 5:00 p.m. Central Time.

NOTICE: DO NOT RETURN PRODUCT TO RETAIL STORE.

Campvalley (Xiamen) Co., Ltd.

No.18th, West Road 3, Jinyuan, Jimei District, Xiamen, Fujian 361022 (China)

Made in China • Printed in China