

SR-DE103

Microcomputer Controlled/ Fuzzy Logic Rice Cooker

Menu Select

Warm

White Rice

Quick Cook

Attractive, Compact Design

Fits on your kitchen counter or dinner table for convenient service.

Domed Lid Design

Helps prevent accumulated water droplets from re-entering the rice.

Easy-to-Read Display

A quick glance tells you the cooking status.

Advanced Fuzzy Logic Technology

Adjusts power & cooking time automatically for precise and consistent results every time.

No need to manually lift the lid when your hands are busy with other things.

Pushbutton Lid Release

Keep Warm Feature

When cooking is complete, the unit automatically switches to Keep Warm Mode and rice is maintained at the perfect temperature.

MICROCOMPUTER White Rice Time Porridge Quick Cook Cake BrownRice Slow Cook

Sticky Rice Steam TIMER & MEMORY Cooking min Timer hour

Panasonic SR-DE103

24-Hour Preset Timer Timer function lets you control

Keep

Warm


cooking start time so fresh-cooked rice is ready when you are.

8 Pre-Program **Control Panel**

Lets you select up to 8 pre-programmed cooking options.







White Slow Cook Brown (3 hrs.) Sticky Cake Quick Cook Porridge

Inner Lid

Inner lid allows for easy cleaning.

Detachable Power Cord

Remove the power cord for tidier storage or when serving rice right out of the cooker.



Included Accessories

Rice Scoop, Measuring Cup, Steaming Basket





Model		<u> </u>	Design	Features Features									Power		Dimensions & UPC										
Model Number	Capacity (cooked rice)		Display	Inner Cooking Pan	Cover	Operational		Menu Options		Preset					Multi-Lingual			Master Pack			Carton		Unit		UPC
							Fuzzy Logic	Rice Only	Other	Timer (Rice only)	Auto Keep V Shutoff Tim	Keep Warm Time	rm Convenience	Accessories	Operating Instructions	Power Supply	Power Consumption	Qty.	W x D x H (in.)	Gross Weight (lbs.)	W x D x H (in.)	Net Weight (lbs.)	W x D x H (in.)	Unit Weight (lbs.)	t 8-85170-
SR-DE103	up to 10 cups	White w/ Silver Trim	Gray LCD Control Panel	Black Non-Stick Coated Aluminum	Pushbutton Lid	Microcomputer Controlled with 8 Menu Options	Yes	White Brown Sticky Quick Cook	Steam Slow Cook (3 hrs.) Cake Porridge	Set finish time up to 24 hrs. in advance		Lid Heater/ Side Heater (12H)	Removable Inner Lid Carrying Handle Pushbutton Lid Release Easy to Read Display START & KEEP WARM Indicator Lights	Measuring Cup Rice Scoop Steaming Basket Detachable Power Cord	English Chinese Spanish French Korean	120 AC;60Hz	Cooking: 750 watts Keep Warm: 89 watts	2	30-5/16 x 11-1/16 x 9-1/8	13.6	15-1/8 x 11 x 9-1/16	6.8	13-13/16 x 10-1/4 x 7-3/4	6.2	02594-3

Start

Off

Porridge

Slow Cook

Cooking

Cake

Steam

min

Panasonic SR-DE103

SR-DE103

12 13