

9ft LED Solar Market Umbrella Assembly, Care and Use Manual

ITEM # UMB-618749T UMB-618749B UMB-618749N



IMPORTANT, RETAIN FOR FUTURE REFERENCE: READ CAREFULLY

For assistance with assembly or installation, parts or problem resolution, please do not return to place of purchase, call customer service at:

ATLeisure LLC 1-855-880-7205 (English Only) 8:00am-5:00pm, Monday to Friday, Eastern Standard TIme www.atleisure.com • Email: customerservice@atleisure.com

Contents

Preparation	
Package Contents	
Set-Up and Operation	
Battery Replacement	
Care and Maintenence	6
Warning and Cautions	6
Warranty & Filing a Claim	

Preparation


Before beginning product assembly, make sure all contents are present. Compare parts with package contents list and diagram. If any part is missing or damaged, do not attempt to assemble the product or return to the place of purchase. Contact our customer service toll free at **1-855-880-7205** for replacement parts or further instructions.

Estimated Assembly Time: 10 minutes No tools required for assembly.

Package Contents

С

Solar Panel




1

Set-Up and Operation


CAUTION: Do not use sharp tools or equipment such as a knife or scissors when removing the protective material, as it may damage the product.

i


INFORMATION: Please remove the plastic film on the solar panel. This protective film is to prevent damage during shipping. Failure to remove the film will result in the solar panel not functioning properly.




the solar panel.




Step 1: Insert the plug into the socket under Step 2: Put the solar panel on the top of umbrella and hide the plug and wire inside the gro ove at the top of umbrella. Then turn the solar panel clockwise. Do not over tighten.





Step 3: Insert the bottom pole into the upper pole while pressing the snap button on the upper pole until the the snap button locks into position.

Step 4: We recommend that you stand and secure the umbrella to an umbrella base (not included). Secure the umbrella pole firmly by tightening the locking nut.



Step 5: Put the solar umbrella in direct sunlight to charge the batteries for 8 hours before the first use.


CAUTION: YOU MUST CHARGE BATTERY BEFORE FIRST USE. Please note that battery can discharge if they are left unused or uncharged for a long period of time. Since there can be a six-month period between production and final customer purchase, we recommend you charge your solar umbrella for at least 8 hours in direct sunlight before the first use. Failure to charge the battery will result in premature dimming of the lights in your new solar umbrella. For everyday normal use, turn the light switch on at night when you want to use the solar light and turn off the switch after use. MAKE SURE THE LIGHT SWITCH IS IN THE OFF POSITION AND IN DIRECT SUNLIGHT FOR THE SOLAR PANEL TO RECHARGE THE BATTERY


Step 6: To open the umbrella, turn the crank handle in the clockwise direction until the canopy is fully open.

Step 7: To tilt the umbrella to your desired angle, press the Tilt Button to release the umbrella top then release the button to maintain the desired angle.


Step 8: Press the light switch to turn on/off the solar lights.

Step 9: To close the umbrella, the main pole must be in the upright position, then continue to crank counterclockwise or opposite direction to close umbrella. Use tie straps to secure canopy.







Step 1:Twist counterclockwise and remove the solar panel from the top of he umbrella.




Step 2: Pull the plug out of the socket under the solar panel. Pull by holding the plug, not by pulling on the wires.



Step 3: Place the solar panel upside down Step 4: Carefully open the bottom case and on a flat, non-abrasive surface to avoid scratching. Remove two (2) screws on the the +/- on the battery with the +/- on the solar panel bottom case.



set aside. Replace the battery, matching battery case.



Step 5: Carefully put the bottom case back. Align the screw holes and replace the screws. Do not over tighten the screws.

Care and Maintenance

See the enclosed Sunbrella® care and cleaning insert for canopy maintenance.

Warnings and Cautions

DANGER: Keep children out of the assembly area during assembly.



WARNING: Read the entire instructions before beginning and follow the steps outlined. Failure to assemble and install as instructed could result in the umbrella tipping over causing personal injury and/or property damage.



WARNING: Do not use this umbrella during periods of high winds and rain. Failure to do so may result in personal injury and/or damage.



CAUTION: Assemble and use umbrella on flat ground.



INFORMATION: Recommend inserting the umbrella into an umbrella base (not included) to secure umbrella in an upright position.



INFORMATION: Close the umbrella and use the canopy ties when umbrella is not in use.



INFORMATION: Schematics in this manual are for assembly and operation illustration only. They may differ from the umbrella's actual appearance.

Battery Replacement and Disposal Instructions

- For best results, use 18650 Lithium 2000mAh are supplied with panel) rechargeable batteries.
- Install only new batteries of the same type in your product.
- Failure to insert batteries in the correct polarity, as indicated in the battery compartment, may shorten the life of the batteries or cause batteries to leak.
- Do not mix old and new batteries.
- Do not mix Alkaline, Standard (Carbon-Zinc) or Rechargeable (Nickel Cadmium) or (Nickel Metal Hydride) batteries.
- Do not dispose of batteries in fire.
- Batteries should be recycled or disposed of as per state and local guidelines.

Made in China

Warranty

This product is covered under a manufacturer's 2-year warranty from date of purchase against defects in materials and workmanship. This warranty does not cover damage due to neglect, abuse or weather related damage. For full warranty disclosure, email us at customerservice@atleisure.com, call toll free at **1-855-880-7205** or send mail to:

Atleisure, LLC Customer Service Dept. 1040 Boulevard SE Ste. B Atlanta GA 30312.

NOT COVERED UNDER WARRANTY

This warranty excludes the following: acts of nature (i.e. wind, fire or freeze); damage caused by improper assembly, accident, disaster, misuse, abuse, negligence and discoloration or fading of the finish as a result of exposure to the elements. Product not intended for commercial use. This warranty gives you specific rights, and you may also have other rights which may vary from state to state.

Filing a Claim

If you are within your warranty, to file a claim you must have your receipt and pictures of your damaged umbrella and send to ATLeisure at:

customerservice@atleisure.com

or by mail to:

Atleisure, LLC Customer Service Dept. 1040 Boulevard SE Ste. B Atlanta GA 30312

Replacement Parts

For replacement parts, call our customer service department at **1-855-880-7205**, 8:00am-5:00pm., EST, Monday-Friday.

DESCRIPTION	PICTURE	Re-order No.
Solar Panel		SOL-PEZT2-T
Bottom Pole	0	BMP-38ASN-BRZ-T
Canopy		CAN-9MDT8RBS-T-BE-RD-NB

U.S. Patent No. 7,533,679 and U.S. Patent No. 7,604,015.



www.atleisure.com ATLANTA, GEORGIA, USA **Customer Service Toll Free 1-855-880-7205** Monday through Friday from 8am-5pm (Eastern Standard Time)