


TPP640S  
thera|pure®  
uv air purifier



TPP640S

thera|pure®  
uv air purifier

Thank you for purchasing the Therapure® 64oS air purifier. With UV light and cleanable HEPA-type filtration to clean the air, the Therapure® 64oS air purifier will greatly improve the quality of the air in your home, office or other environments. We want you to be fully satisfied with your Therapure® 64oS. That's why your Therapure® 64oS comes with a one-year limited warranty.

Once you've experienced the purity of Therapure® 64oS air, visit us at our website to find out more ways to improve the quality of your air and your life with our premium products and upgrades.

Please be sure to read the following instructions carefully to ensure optimal performance and safety.

[www.envionproducts.com](http://www.envionproducts.com)

Therapure® by Envion, LLC  
P.O. Box 9159  
Van Nuys, CA 91409-8291  
800.875.8577

TPP64oS

therapure®

by **ENVION**®

## TABLE OF CONTENTS

<b>SAFETY INSTRUCTIONS</b>	<b>2</b>
<b>IMPORTANT WARNINGS</b>	<b>3</b>
UV Lamp Notice	3
Mercury Notice	3
UV Lamp Disposal Notice	3
UV Lamp Breakage	3
<b>PRODUCT BENEFITS</b>	<b>4</b>
<b>MAIN PARTS</b>	<b>5</b>
<b>OPERATING THE THERAPURE® 64oS AIR PURIFIER</b>	<b>6</b>
Air Purifier Specifications	6
Getting Ready	7
Controls/Settings	8
<b>CLEANING &amp; MAINTENANCE</b>	<b>9</b>
Cleaning the Cleanable Filter	9
Resetting the Clean Filter Indicator	9
Maintenance UV Lamp	10
Cleaning Pre-Filter	10
Cleaning External Surfaces	10
Replacing the UV Lamp	11
Cleaning the Air Monitor	12
<b>TROUBLE-SHOOTING</b>	<b>12</b>
<b>ONE-YEAR LIMITED WARRANTY</b>	<b>13</b>

## SAFETY INSTRUCTIONS

### READ AND SAVE THESE INSTRUCTIONS

#### WARNING: RISK OF ELECTRICAL SHOCK

Safety precautions should always be used when operating this or any electrical appliance. Decrease the risk of electrocution, electric shock, injury or fire by reading and following all the warnings below.

Use only as described in this Therapure® 64oS manual. To reduce the risk of electric shock, do not attempt to service the product in any way other than in the manner described in the “Cleaning & Maintenance” section of this manual.

#### READ ALL INSTRUCTIONS BEFORE OPERATING THE AIR PURIFIER.

- » This product operates at 120V AC, 60Hz only.
- » Do not run cord under carpeting. Do not cover cord with throw rugs, runners, or similar coverings. Arrange cord away from traffic area and where it will not be tripped over.
- » Do not operate the product in any greasy environment, such as in the kitchen. This product is not intended to filter oil or grease from the air.
- » Do not use the Therapure® 64oS air purifier in bathrooms or other humid environments. Do not use near fireplaces or in areas where flammable or combustible vapors or products may exist.
- » Always unplug the power cord from the electrical outlet when the purifier is not in use, before cleaning, inserting or removing parts or before moving to another location.
- » Never run the air purifier unless it is fully assembled.
- » This appliance has a polarized plug (one blade is wider than the other). To reduce the risk of electric shock, this plug is intended to fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do not attempt to defeat this safety feature.
- » Always turn off all controls before unplugging the Therapure® 64oS air purifier from the outlet.
- » Attempting to service the Therapure® 64oS air purifier in any way that is not described in this owner’s manual will cause the warranty to be voided and could cause serious personal injury to the user and/or result in considerable damage to the unit.
- » Do not place the cord near a heated surface.
- » Do not operate this product with a damaged cord or plug. Discard the product or return to an authorized service facility for examination and/or repair.
- » Never use the power cord to pick up, carry, drag, pull, or lift the Therapure® 64oS air purifier. Do not pull the cord against or around sharp corners and edges. This could result in injury to the user or damage to the cord.
- » Always remove the plug from its power outlet by holding onto the plug itself and pulling gently.
- » Never pull on the cord itself to unplug it from its power outlet.
- » Use care when operating the Therapure® 64oS air purifier by keeping all foreign objects, fingers, body parts, hair, loose clothing and jewelry away from openings.
- » Never touch the Therapure® 64oS air purifier or its plug when your hands are wet.
- » The Therapure® 64oS air purifier is an electrical appliance. Adult supervision is required when operating the Therapure® 64oS in the presence of children.
- » To reduce the risk of fire or electric shock, do not use this air purifier with any solid-state speed control devices.

## IMPORTANT WARNINGS

#### UV Lamp Notice

UV Light is harmful to bare skin and eyes and can cause temporary or cleanable loss of vision. Never look directly at the UV lamp while it is illuminated; doing so could cause loss of vision! Only view illumination through the window at the front of the unit. To prevent exposure to ultraviolet light, disconnect the power to the unit before servicing any part of the Therapure® 64oS air purifier.

#### UV Lamp Disposal

If the UV lamp breaks, turn off the unit. Do not operate the unit with a broken lamp. Do not use a vacuum to clean up breakage. Sweep debris into a plastic bag and dispose of properly. Contact your local waste management authority for instructions regarding recycling and the proper disposal of old lamp(s). To order a replacement lamp, call **1.800.875.8577** or go to **www.envionproducts.com**.

#### Mercury Notice

Because the Therapure® 64oS contains a light bulb and light bulbs contain mercury, Envion is required to provide the following warning:

**WARNING:** This product contains mercury, a chemical known to the State of California to cause birth defects or other reproductive harm.

Do not place your used lamp(s) in the trash. Disposal of any item containing mercury must be in accordance with any hazardous waste disposal or recycling laws and regulations of your state.

This product complies with the maximum allowable concentration of ozone of 0.050 parts per million by volume (ppmv) in a 24-hour period. The Health Canada Guideline 2010 recommends that the maximum exposure limit, based on an averaging time of 8 hours, is 0.020 ppmv or less when tested in a sealed, controlled room approximately 30 m<sup>3</sup>.

# TPP64oS

## PRODUCT BENEFITS

### >> 5 - Stage purification process:

1. Pre-Filter.
2. Cleanable HEPA-type Filter.
3. UV lamp.
4. Photo catalyst filter.
5. ION boost.

### >> 3 speed fan setting—lets you select the desired cleaning level.

### >> Auto mode to automatically adjust fan speed depending on air quality.

- **RED** means air quality is poor.
- **ORANGE** means air quality is fair.
- **BLUE** means air quality is good.


### >> 24-hour timer for automatic power off.

### >> Night mode to dim the control panel light when you sleep

### >> Clean filter indicator.


### >> Remote Control.

# TPP640S



## MAIN PARTS

1. Locking Latch
2. Air Inlet Grill
3. Pre Filter
4. Cleanable HEPA-type Filter
5. UV Lamp Cover
6. Control Panel: Time, On/Off, Speed, UV/VOC, Auto, ION and Night Mode
7. Air Quality Indicator Light
8. Air Outlet Grill
9. UV Lamp



## OPERATING THE THERAPURE® TPP640S

Before using the Therapure® 640S air purifier, please read the following important information.


### Electrical Ratings:

- 120V Setting: 120Vac, 60 Hz
- Power consumption: 55 watts (0.45 ampere) at high fan speed,
- 3 watt UV light bulb
- Net weight: 9.5 lbs
- Dimension (L x W x H): 8.7" x 7.5" x 25.2"

### Replacement Parts:

Lamp – TPP2400  
Filter – TPP6400F  
Pre Filter – TPP6400P

Locate a level surface on which to place the Therapure® 640S air purifier near a 120V outlet (follow warnings in the **“SAFETY INSTRUCTIONS”** and **“IMPORTANT WARNINGS”** sections of this manual). Position your Therapure® 640S at least one foot (12 inches) from the wall. Plug in the unit.




## OPERATING THE THERAPURE® TPP640S

Before using the Therapure® 640S air purifier, please read the following important information.

### Safety

1. Do not place near fans.
2. Keep both sides of the unit at least 1 foot away from a wall.
3. Do not place the unit near curtains.
4. Placing the unit close to the source of air pollution is an effective way to improve indoor air quality.



### Note:

DO NOT run the Therapure® 640S with a broken filter. Replace the filter if the filter has a tear or a hole in it.

If the filter is damaged or needs replacement, please visit the Therapure® website at [www.envionproducts.com](http://www.envionproducts.com) to order for a replacement filter. Or call 1.800.875.8577.

## OPERATING THE THERAPURE® TPP640S

### CONTROLS/SETTINGS:


**Power Control** – To operate the Therapure® 640S, press the Power  button to turn on the air purifier.

**Timer Control** – The Therapure® 640S air purifier can be programmed to turn off after a preset amount of time. Press the “TIME” button to program the timer. Each press will add one hour up to a total of 24 hours. Keeping the button pressed will automatically increase to 24 hours, 1 hour at a time, after that it will turn back to off.

**ION Generator** – Press the ION button to turn on the IONs. Press it again to turn the IONs off.

**Fan Speed Control** – The Therapure® 640S has three different speeds of cleaning, LOW, MED and HI. Press “SPEED” button to cycle the settings and select the fan speed you desire. The speed state will be shown on the LED display.


**Auto Mode** – The Therapure® 640S is equipped with an air sensor to monitor the quality of your air. Simply press the Auto button to activate the air monitoring system. The monitor will test the air quality and automatically adjust the fan speed to remove the air contaminants. The front of the display is equipped with LED lights to notify you of the air quality. **RED** color is for poor, **ORANGE** for fair and **BLUE** for good quality air.



**Clean Filter Indicator Light** – The Therapure® 640S Clean Filter Indicator Light will turn on each time the filter needs to be cleaned. To reset the filter indicator, press the ION and UV/VOC buttons together for 3 seconds. The CLEAN FILTER light will flash 3 times and then turn off completely, indicating the unit has been reset.

**Dim Mode** – If the LED lights are too bright, activate the “Dim Mode” to turn off the LED lights and the lighted display. To turn on Dim mode, simultaneously press Auto and Time buttons. Power indicator, however, will remain lit.

**UV Control** – Press the UV/VOC control button “UV/VOC” to turn on the UV lamp and the photocatalyst filter.



## CLEANING & MAINTENANCE

Keep the Therapure® 640S functioning properly by cleaning the cleanable HEPA-type Filter every four weeks of use. More frequent cleaning will be necessary if the unit is located in an area with a high level of airborne contaminants (excessive amounts of smoke, pet dander, etc.).


Exposing the Therapure® 640S to candle/oil/fireplace soot and smoke is not recommended and will require more frequent cleaning.

**NOTE: Always make sure the Therapure® 640S is turned off and unplugged before cleaning.**

- » **Vacuuming will restore performance of the cleanable HEPA-type Filter. However, the filter may appear stained. This is normal and does not affect performance in any way.**
- » **Do not use water or any household cleaners or detergents to clean the cleanable HEPA-type Filter.**
- » **The inlet grill may be cleaned (after unit is turned off and unplugged) with a vacuum or a slightly damp cloth.**

### Cleaning the cleanable HEPA-type Filter

1. Release the inlet grill by pressing on the locking latch (see diagram of Main Parts).
2. Remove the inlet grill from the unit as shown below.
3. Grasp the left and right frames of the cleanable HEPA-type Filter through the indentations on the sides of the filter enclosure and remove the filter.
4. To clean the cleanable HEPA-type Filter, use the brush or crevice attachment with a vacuum cleaner. Run the attachment along the inlet and outlet side of the filter, cleaning between the crevices as much as possible. **Do not use water or any household cleaners or detergents to clean the cleanable HEPA-type Filter.**
5. Once the cleanable HEPA-type Filter has been cleaned and checked for any possible damage, replace the filter back in the reverse direction described here. Plug in the unit and **hold down the ION + UV/VOC button for 3 seconds**. The clean filter light will go off and your cleaning maintenance is done.



## CLEANING & MAINTENANCE

### Cleaning the Pre-Filter

1. Release the air inlet grill by pressing on the locking latch.
2. Gently remove the pre-filter from the air inlet grill.
3. To clean the pre-filter, simply submerge in warm soapy water. Gently lift and submerge the pre-filter several times until it is clean.
4. Rinse the pre-filter with clean water and allow it to dry completely before placing it back to the air inlet grill.

### Cleaning External Surfaces

1. Turn off and unplug unit.
2. Use a washcloth slightly dampened with a little water and dishwashing soap to wipe the outer case surfaces.
3. Do not allow water to slip into the internal parts as this could damage your unit and result in electrical shock and injury to you.
4. Allow the unit to thoroughly dry before use.

### UV Lamp

The lifetime of the UV lamp is up to 12 months of continuous, effective operation. After this time, the bulb may remain illuminated, but its effectiveness is greatly reduced. **For maximum effectiveness, please replace the UV bulb annually.**


**If the lamp stops functioning or needs replacement, please visit our web site at [www.envionproducts.com](http://www.envionproducts.com) to order a replacement lamp. Or call 1.800.875.8577.**

### Caution:

- Do not touch the glass part of the lamp. Oil from fingertips will decrease the effectiveness of the lamp.
- Never operate the unit without a filter or with a damaged filter. UV lamp cover must be installed at all times. The UV light from the UV lamp will result in severe damage to eyes and could cause blindness.

### UV Lamp Notice Warning:

UV Light is harmful to bare skin and eyes and can cause temporary or cleanable loss of vision. Never look directly at the UV lamp while it is illuminated-doing so could cause loss of vision!




# TPP640S

## CLEANING & MAINTENANCE

**Before replacing the UV lamp, make sure the Therapure® 640S air purifier is turned off and unplugged. Let the lamp cool down for 5 minutes before replacing it.**

### Replacing the UV Lamp:

1. Release the inlet grill by pressing on the locking latch.
2. Grasp the left and right frames of the cleanable HEPA-type filter through the indentations on the sides of the filter enclosure and remove filter.
3. Remove the two bolts used to fix the UV lamp cover and remove the cover out from the unit then unscrew the old UV lamp from the lamp base of the unit.
4. Install the new UV lamp into the lamp base of the unit.
5. Install the UV lamp cover with the two bolts on the unit.
6. Install the inlet grill on the unit.



## CLEANING & MAINTENANCE

### Cleaning the Air Monitor:

The TPP640S is designed with an air monitor to track the quality of your air. Over time the monitor can become dirty and may require cleaning. The main symptom of a dirty air monitor is the LED display remains frozen on one light color. In order to clean the air monitor you must use a vacuum to clear the monitor chamber.

1. Power off and unplug unit.
2. Locate the 3 small vent holes in the rear of the unit just about the inlet grill. (Fig. 1)
3. Use a vacuum cleaner hose to suction any dust or dirt that may have accumulated inside the monitor chamber. (Fig. 2)

Figure 1





Figure 2



## TROUBLESHOOTING

PROBLEM	REASON	SOLUTION
<b>Unit will not operate.</b>	Power button has not been turned on.	Press the Power button
	Unit is unplugged.	Check to ensure unit is plugged in.
	The inlet grill has not been installed & locked into place.	Check to make sure filter and inlet grill is properly installed & locked into place.
<b>Reduced airflow or poor filtering.</b>	The inlet or outlet grill may be blocked.	Check to ensure nothing is blocking air inlet & air outlet.
	Cleanable filter may be clogged.	Check & clean filter, if necessary.

## ONE-YEAR LIMITED WARRANTY

### ONE YEAR LIMITED WARRANTY

Your Therapure® 640S air purifier is warranted to be free from defects in materials and workmanship for one year from the original purchase date. Should the product have a defect in materials or workmanship, we will repair or replace it without charge to you (a shipping and processing fee will apply). To obtain service under warranty, simply call our customer service center toll-free at **800.875.8577** – M-F 7-4 PST / 7-3 Sat.

This warranty does not cover damage caused by accident, misuse or any use other than as intended and described in this product manual, or damage resulting from failure to maintain and clean this product as specified in this product manual. This warranty applies only to the original purchaser of the Therapure® 640S air purifier.

**ALL EXPRESS AND IMPLIED WARRANTIES FOR THIS PRODUCT, INCLUDING IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, ARE LIMITED IN DURATION TO THE WARRANTY PERIOD, AND NO WARRANTIES, WHETHER EXPRESS OR IMPLIED, WILL APPLY AFTER THIS PERIOD.**

Some states do not allow limitations on the duration of implied warranties, so the above limitation may not apply to you. While this warranty gives you specific legal rights, you may also have other rights which may vary from state to state.

### Contact Info for Warranty Service:

Therapure® by Envion LLC

P.O. Box 9159 | Van Nuys, CA | 91409-8291  
1.800.875.8577 | www.envionproducts.com

©2016 Envion, LLC. All Rights Reserved. Patents pending.

The energy efficiency of this ENERGY STAR qualified model is measured based on a ratio between the model's CADR for dust and the electrical energy it consumes, or CADR/Watt.



**TPP640S** | **therapure®**  
uv air purifier

by **ENVION®**

TPP640S